

**List of HP LaserJet printer models supported**  
(Part1 : Monochrome printers)

Black & white laser printers		Black & white multifunction printers	
Printer model	BlueKit Part number	Printer model	BlueKit Part number
HP LaserJet M406 / M407 * (New)	999361-003	HP LaserJet MFP M430 * (New) HP LaserJet MFP M431 * (New)	999361-004
HP LaserJet M506 *	999358-069	HP LaserJet 500 MFP M525	999358-042
HP LaserJet M507 *	999359-016	HP LaserJet MFP M527 * HP LaserJet MFP M528 *	999358-070
HP LaserJet M604 / M605 / 606 *	999358-066	HP LaserJet MFP M630	999358-065
HP LaserJet M607 *	999358-073	HP LaserJet MFP M631 *	999358-076
HP LaserJet M608 *	999358-074	HP LaserJet MFP M632 *	999358-077
HP LaserJet M609 *	999358-075	HP LaserJet MFP M633 *	999358-078
HP LaserJet M610 HP LaserJet M611 HP LaserJet M612 *	999359-018	HP LaserJet MFP M634 * HP LaserJet MFP M635 * HP LaserJet MFP M636 *	999359-019
HP LaserJet 600 M601 / M602 / M603	999358-041	HP LaserJet 700 MFP M725	999358-048
HP LaserJet 700 M712	999358-045	HP LaserJet MFP M830	999358-051
HP LaserJet M806	999358-050	HP LaserJet MFP E42540 * (New)	999361-008
HP LaserJet E40040 * (New)	999361-007	HP LaserJet MFP E52545 * HP LaserJet MFP E52645 *	999359-012
HP LaserJet E50045 * HP LaserJet E50145 *	999359-015	HP LaserJet MFP E62555 * HP LaserJet MFP E62565 * HP LaserJet MFP E62575 *	999359-002
HP LaserJet E60055 * HP LaserJet E60065 * HP LaserJet E60075 * HP LaserJet E60155 * HP LaserJet E60165 * HP LaserJet E60175 *	999359-001	HP LaserJet MFP E62655 * HP LaserJet MFP E62665 * HP LaserJet MFP E62675 *	
HP LaserJet 2410 HP LaserJet 2420 HP LaserJet 2430	999356-006	HP LaserJet MFP E72525 * HP LaserJet MFP E72530 * HP LaserJet MFP E72535 * HP LaserJet MFP E72625 * HP LaserJet MFP E72630 * HP LaserJet MFP E72635 *	999359-003
HP LaserJet P3005	999358-003	HP LaserJet MFP E73130 * (New) HP LaserJet MFP E73135 * (New) HP LaserJet MFP E73140 * (New)	999361-011
HP LaserJet P3010 HP LaserJet P3014 HP LaserJet P3015	999358-028	HP LaserJet MFP E82540 * HP LaserJet MFP E82550 * HP LaserJet MFP E82560 *	999359-004
HP LaserJet P4014 HP LaserJet P4015 HP LaserJet P4515	999358-019	HP LaserJet MFP E82640 * (New) HP LaserJet MFP E82650 * (New) HP LaserJet MFP E82660 * (New)	999361-012
HP LaserJet 4240 / 4250	999356-001	HP LaserJet M3035 MFP	999358-004
HP LaserJet 4350	999356-002	HP LaserJet 4345 MFP	999356-007
HP LaserJet 5200	999356-013	HP LaserJet M4345 MFP	999358-006
HP LaserJet 9040 / 9050	999356-005	HP LaserJet M4555 MFP	999358-037
		HP LaserJet M5035 MFP	999358-005
		HP LaserJet 9040 MFP HP LaserJet 9050 MFP	999356-008
		HP LaserJet M9040 MFP HP LaserJet M9050 MFP	999358-018

**List of HP LaserJet printer models supported**  
(Part2: Color printers)

Color laser printers		Color multifunction printers	
Printer model	BlueKit Part number	Printer model	BlueKit Part number
HP Color LaserJet M455 * (New)	FULL Color 999362-001 B&W 999361-001	HP Color LaserJet MFP M480 * (New)	FULL Color 999362-002 B&W 999361-002
HP LaserJet 500 Color M551	FULL Color 999358-039 B&W 999358-038	HP LaserJet 500 Color MFP M575	FULL Color 999358-044 B&W 999358-043
HP LaserJet Color M552 * HP LaserJet Color M553 *	FULL Color 999358-068 B&W 999358-067	HP Color LaserJet MFP M577 * HP Color LaserJet MFP M578 *	FULL Color 999358-072 B&W 999358-071
HP LaserJet Color M554 * HP LaserJet Color M555 *	FULL Color 999360-013 B&W 999359-022	HP Color LaserJet MFP M680	FULL Color 999358-062 B&W 999358-058
HP Color Laser M651	FULL Color 999358-061 B&W 999358-057	HP Color LaserJet MFP M681 *	FULL Color 999358-081 B&W 999358-085
HP Color Laser M652 *	FULL Color 999358-083 B&W 999358-079	HP Color LaserJet MFP M682 *	FULL Color 999358-082 B&W 999358-086
HP Color Laser M653 *	FULL Color 999358-084 B&W 999358-080	HP LaserJet 700 Color MFP M775	FULL Color 999358-047 B&W 999358-046
HP Color Laser M750	FULL Color 999358-054 B&W 999358-049	HP Color LaserJet MFP M880	FULL Color 999358-056 B&W 999358-053
HP Color LaserJet M855	FULL Color 999358-055 B&W 999358-052	HP Color LaserJet MFP E57540 *	FULL Color 999360-009 B&W 999359-014
HP Color LaserJet E45028 * (New)	FULL Color 999362-003 B&W 999361-005	HP Color LaserJet MFP E47528 * (New)	FULL Color 999362-004 B&W 999361-006
HP Color LaserJet E55040 *	FULL Color 999360-015 B&W 999359-025	HP Color LaserJet MFP E67550 * HP Color LaserJet MFP E67560 * HP Color LaserJet MFP E67650 * HP Color LaserJet MFP E67660 *	FULL Color 999360-002 B&W 999359-006
HP Color LaserJet E65050 * HP Color LaserJet E65060 * HP Color LaserJet E65150 * HP Color LaserJet E65160 *	FULL Color 999360-001 B&W 999359-005	HP Color LaserJet MFP E77820 * HP Color LaserJet MFP E77830 *	FULL Color 999360-003 B&W 999359-007
HP Color LaserJet E75245 *	FULL Color 999360-012 B&W 999359-021	HP Color LaserJet MFP E78323 * HP Color LaserJet MFP E78325 * HP Color LaserJet MFP E78330 *	FULL Color 999360-011 B&W 999359-020
HP Color LaserJet 3000	FULL Color 999358-012 B&W 999358-002	HP Color LaserJet MFP E78630 * (New) HP Color LaserJet MFP E78635 * (New)	FULL Color 999362-005 B&W 999361-009
HP Color LaserJet CP3505	FULL Color 999358-013 B&W 999358-008	HP Color LaserJet MFP E87640 * HP Color LaserJet MFP E87650 * HP Color LaserJet MFP E87660 *	FULL Color 999360-004 B&W 999359-008
HP Color LaserJet CP3525	FULL Color 999358-024 B&W 999358-023	HP Color LaserJet MFP E87740 * (New) HP Color LaserJet MFP E87750 * (New) HP Color LaserJet MFP E87760 * (New)	FULL Color 999362-006 B&W 999361-010
HP Color LaserJet 3800	FULL Color 999358-014 B&W 999358-001	HP Color LaserJet CM3530 MFP	FULL Color 999358-025 B&W 999358-026
HP Color LaserJet CP4025	FULL Color 999358-030 B&W 999358-029	HP Color LaserJet CM4540 MFP	FULL Color 999358-036 B&W 999358-035

HP Color LaserJet CP4525	<b>FULL Color</b> 999358-032 B&W 999358-031	HP Color LaserJet 4730 MFP	<b>FULL Color</b> 999356-010 B&W 999356-016
HP Color LaserJet 4650	<b>FULL Color</b> 999356-014 B&W 999356-003	HP Color LaserJet CM4730 MFP	<b>FULL Color</b> 999356-017 B&W 999356-020
HP Color LaserJet 4700	<b>FULL Color</b> 999356-014 B&W 999356-012	HP Color LaserJet CM6030 MFP HP Color LaserJet CM6040 MFP	<b>FULL Color</b> 999358-021 B&W 999358-027 *
HP Color LaserJet CP5525	<b>FULL Color</b> 999358-034 B&W 999358-033	HP CM8050 Color MFP	<b>FULL Color</b> 999358-015 B&W 999358-010
HP Color LaserJet 5550	<b>FULL Color</b> 999356-018 B&W 999356-004	HP CM8060 Color MFP	<b>FULL Color</b> 999358-016 B&W 999358-011
HP Color LaserJet CP6015	<b>FULL Color</b> 999358-022 B&W 999358-017	HP Color LaserJet 9500 MFP	<b>FULL Color</b> 999356-019 B&W 999356-009

**List of HP Officejet printer models supported**  
(Part3: Color printers)

Color printers		Color multifunction printers	
Printer model	BlueKit Part number	Printer model	BlueKit Part number
HP Officejet Color X555	<b>FULL Color</b> 999358-063 B&W 999358-059	HP Officejet Color MFP X585	<b>FULL Color</b> 999358-064 B&W 999358-060

**List of HP Page Wide printer model supported**  
(Part4: Color printers)

Color printers		Color multifunction printers	
Printer model	BlueKit Part number	Printer model	BlueKit Part number
HP PageWide Color 556 *	<b>FULL Color</b> 999358-088 B&W 999358-087	HP PageWide Color MFP 586 *	<b>FULL Color</b> 999360-005 B&W 999359-009
		HP PageWide Color MFP E58650 *	<b>FULL Color</b> 999360-008 B&W 999359-013
		HP PageWide Color MFP 780 * HP PageWide Color MFP 785 *	<b>FULL Color</b> 999360-007 B&W 999359-011
		HP PageWide Color MFP E77650 * HP PageWide Color MFP E77660 *	<b>FULL Color</b> 999360-006 B&W 999359-010
		HP PageWide Color MFP P77940 * HP PageWide Color MFP P77950 * HP PageWide Color MFP P77960 *	<b>FULL Color</b> 999360-010 B&W 999359-017

\* : Optional HP USB internal interface B5L28A can be purchased directly at <https://www.hp.com>